

CLEANING/DISINFECTING YOUR MSA FIRE HELMET



1 Gross Decontamination at Fire Scene
Rinse helmet with water directly on site before doffing. If not possible to rinse with water, perform a dry pre-cleaning with microfiber cloths.

2 Gross Cleaning at Fire Station
In case of highly soiled helmets, perform manual pre-cleaning with warm water and soap.

3 Final Cleaning
Complete helmet can be cleaned without disassembly, by hand or in a fixed-basket washing machine. Remove all electronics prior to cleaning.
For daily cleaning, clean leather soft goods by hand without disassembly and remove textile soft goods and neck curtain and clean by hand or in tumbling machine.

4 Disinfection
In addition to regular cleaning, the use of a disinfectant is recommended in case of suspicion of exposure to bacteria or virus contamination.

5 Drying
Dry helmet in ambient air, warm room or drying cabinet. Ensure helmet is completely dry for better hygiene and durability.

6 Visual Inspection & Record Keeping
Perform complete check of helmet with detailed inspection of each critical component (suspension, shell, impact liner) according to service and maintenance manuals.